


EN





1. Principal Components

Principal components of the accessory board UNO-DM-COM KIT and UNO-DM-PLUS Ethernet COM KIT are shown in the figures and described in the following table:

Main components


- 01 Inverter connector
- 02 RS485 Line Termination Jumper
- 03 DRM0 Activation Jumper
- 04 Alarm Connector
- 05 Fixing hole
- 06 RS485 and REM connector
- 07 Ethernet communication port (RJ45)
- 08 EMI ferrite



4. Assembly instructions

Caution! Hazardous voltages may be present on accessory board. To avoid the risks for electric shock, the access to the internal zones of the inverter must be carried out after at least 5 minutes following the disconnection of the equipment from the network and from the photovoltaic generator.

- To install the accessory board, perform the following steps:
- Remove the front cover of the UNO-DM-PLUS inverter (Refer to the quick installation guide of UNO-DM-PLUS inverter for proper removal of the front cover)
 - (A): Connect the connector (01) to the counterpart present on the inverter
 - (B): Use the tower with the spring supplied to secure the board to the chassis of the inverter using the appropriate hole (05).



Before turning on the unit, it is mandatory to close the cover of the inverter.

Stick the identification label, present in the documentation kit of the accessory board purchased, on the external side of the inverter nearby the label of approval. This label is useful to understand from the outside if an accessory board is installed on the inverter.

UNO-DM-COM KIT installed inside the inverter, DRM0 supported

OR

UNO-DM-PLUS Ethernet COM KIT installed inside the inverter, DRM0 supported

3. Supplied component list

Inside the package, the following items are supplied:

Available components	Quantity
Accessory Board UNO-DM-COM KIT or UNO-DM-PLUS Ethernet COM KIT	1
Quick installation guide	1
Tower with spring	1
EMI ferrite (08)	2
Cable gland M25	1
Gasket with two/three* holes for the service cable gland M25 + cap TGM613	1 + 1 or 2*

*Gasket with three holes and two pieces of cap TGM613 only on UNO-DM-PLUS Ethernet COM KIT

3. Functional diagram

UNO-DM-COM KIT and UNO-DM-PLUS Ethernet COM KIT are the optional accessory boards that can be integrated in the inverters of the UNO-DM-PLUS family offering the following additional functions:

- Ethernet communication port (RJ45) (Only available on UNO-DM-PLUS Ethernet COM KIT board)
- RS485 communication port for connecting either an external monitoring / control system or a supported meter for implementing a Dynamic feed-in control.
- Remote ON/OFF Digital Input.
- Alarm Contact.
- Demand Response Mode 0 required by AS/NZS 4777.2:2015

The expansion board can be inserted directly into the dedicated connector inside the inverter and can also be easily added to a previously installed inverter.

The installation must be performed by an installer or by a trained technician after reading the instructions given in this guide.

The board is directly powered by the inverter and provides the required safety isolation from the primary side of the inverter.

(Only available on UNO-DM-PLUS Ethernet COM KIT board)
 The Ethernet connectivity is based on Zero-Conf IP protocol with DHCP client.

Ethernet port provides access to the integrated Web User Interface as well as already possible with the WiFi communication channel simultaneously.

Both RS-485 and Ethernet communication ports can be set for enabling communication over either Modbus (RTU and TCP respectively) protocol Sunspec compliant or proprietary communication protocol named Aurora Protocol. Only one client at a time is allowed commissioning the inverter or reading and/or writing the inverter's registers. Available supported Sunspec modes and register map are published.

5.



For more information about the configuration and use of the terminal for communication and control signals, refer to the inverter product manual.

CABLE CONNECTION IN INVERTER VERSIONS WITHOUT WIRING BOX

Each cable connected to the connectors of the accessory board must be passed through the M25 cable gland (supplied) to be installed on the bottom part of the inverter.

The M25 cable gland (that accepts a cable with a diameter ranging between 10 mm and 17 mm) and a gasket with two holes to be inserted inside the cable gland, which allows the passage of two (in case of UNO-DM-COM KIT) or three (in case of UNO-DM-PLUS Ethernet COM KIT) separate cables with a maximum diameter of 6 mm.


To install the M25 cable gland remove the M25 protection cap from the inverter and replace it with the cable gland, fastening it with the same M25 lock nut and the same O-ring of the protection cap.

Caution! To ensure the degree of environmental protection IP65, it is necessary to fix the cable gland to the inverter chassis with a minimum torque of 7.5 Nm. When installing the cable gland M25 use the O-ring removed from the M25 protection cap (installed into the inverter) to maintain the IP65 protection level!

If only a single cable is being passed through the gasket, the TGM613 cap must be inserted into the spare hole to ensure degree of environmental protection (see figure below).


The communication cable (ethernet and/or RS485) must be wrapped around the EMI ferrite 08 supplied in the package (1 winding); such a EMI ferrite should be appropriately placed on the inside bottom side of the inverter compartment (see side illustration and ethernet/RS485 connection paragraph in this guide).

The connection of the communication and control signal cables should be done with no over-length of the above mentioned cables (as in the illustration). i.e. the cables should be run over the internal protective sheet. Moreover the communication and control signal connection cables should not be in contact with AC cables.



CABLE CONNECTION IN INVERTER VERSIONS WITH WIRING BOX


- Remove both front covers (wiring box 05 and inverter compartment 04)
- Insert the appropriate water-tight conduit connector on signal conduit opening 15 and tighten to the chassis to maintain NEMA 4X compliance.
- Conduit must be sealed using water-tight fittings to maintain NEMA Type 4X enclosure integrity.



- Run the cables through the signal cable conduit
- Run the cables through the plastic cable tray on the internal right side of the wiring box
- Run the cables inside the inverter through the hole and connect the cable to the accessory board.


The communication cable (ethernet and/or RS485) must be wrapped around the EMI ferrite 08 supplied in the package (1 winding); such a EMI ferrite should be appropriately placed on the inside bottom side of the inverter compartment (see side illustration and ethernet/RS485 connection paragraph in this guide).

The connection of the communication and control signal cables should be done with no over-length of the above mentioned cables (as in the illustration). i.e. the cables should be run over the internal protective sheet. Moreover the communication and control signal connection cables should not be in contact with AC cables.



To connect the wires to the Alarm 04, RS485 and REM 06 connector terminals:


- 1) With a flathead screwdriver, hold the button corresponding to the contact to be wired.
- 2) Insert the cable.
- 3) Release the button and check the cable seal.



6.

If it's required to use a pre-assembled ethernet cable to be connected to the UNO-DM-PLUS Ethernet COM KIT, it will be necessary to make the following operation:


- A) Remove the gasket with three holes from the M25 cable gland disassembling the thread-lock sealing nut.
- B) Cut the gasket from the edge to an hole with a cutter or a scissor as shown in the pictures.
- C) Insert the Ethernet cable in the hole previously cutted of the gasket with three holes and assemble the gasket with three holes on the M25 cable gland.
- D) Firmly screw the thread-lock sealing nut.



The characteristics required for the ethernet cable are listed in the table below:

Type	Cable diameter
CAT 5E or greater	6 mm max.

The ethernet cable must also be wrapped around the EMI ferrite supplied in the package (1 winding); such a EMI ferrite should be appropriately placed on the inside bottom side of the inverter compartment.




7. RS485 line connection

Characteristics and dimensioning of the communication cables

To connect the RS485 line, you must use a shielded cable with three conductors. The characteristics that the cable must possess are indicated in the following table:

Type	AWG (mm ²)	Characteristic impedance	Operational voltage	Operational temperature
Shielded	24 - 16 (0.2 - 1.5)	120 Ohm	≥300 V	-20...+60 °C


The wiring of the RS485 line must also be wrapped around the EMI ferrite supplied in the package (1 winding); such a EMI ferrite should be appropriately placed on the inside bottom side of the inverter compartment.



Using the RS485 terminals

The RS485 HALF-DUPLEX communication line must consist of two wires of transmission and reception (+T/R and -T/R) and a reference communication cable (RTN).

All three cables are to be connected using daisy chain technique (it's recommended to make the chain connection external to the inverter). The RS485 connection is made using the terminal 06.



The last inverter of the daisy chain must be "terminated". Apply the 120 Ohm termination resistance by configuring the RS485 Line Termination Jumper 02 to the "ON" position.

8.

Connecting the alarm contact and the remote control

Characteristics and dimensioning of the cable for alarm and remote control contact:


AWG / mm ²	Operational voltage	Operational temperature
24 - 16 / 0.2 - 1.5	≥300 V	-20...+60 °C

Using the Alarm terminal

Connections to the configurable ALARM relay are through the terminals 04. This allows connection to external devices to signal fault conditions or load control. The operation mode can be selected in the "INVERTER > SETTINGS > Alarm" menu.

The operation modes that can be selected: Production, Alarm, Alarm Configurable, Crepuscular, Alarm Configurable Latch, Alarm Configurable ext, GoGo relè (Auto), GoGo relè (Remote). Refer to the product manual for further details on the operation modes of the Alarm terminal.

The ALARM contact can only be used with systems that include additional safety insulation (supplementary insulation in relation to the DC input voltage).




Using the REM terminal

The REM terminal 06, when properly configured, allows the use of the "Remote ON / OFF" or the "DRM0" functions.

The inverter can be disconnected from the grid remotely using the REMOTE ON/OFF function. This function is enabled in the "INVERTER > SETTINGS > Remote ON/OFF" menu. To use purely as a REMOTE ON/OFF, the DRM0 jumper 03 must be set to "OFF".

Where required, it is possible to activate the DRM0 function by configuring the Jumper for the activation of the DRM0 function 03 in the "ON" position.

In case the DRM0 function is enabled if the proper connection of the REM terminal is not made, the inverter will remain disconnected. Refer to the product manual for further information on the DRM0 function.



9.

Features and Technical Data

Connections	
Type of connectors	Connectors with spring (Cables accepted: 0.2-1.5 mm ² / 24-16 AWG)
Alarm relay rating	Floating contact (230V, 1A max.)
Remote On/Off	Digital input
Serial communication protocol	ModBus RTU Sunspec compliant or Aurora Protocol
Safety	
Brands	CE
Class of insulation	I
EMC and safety standards	EN 60950-1; EN 55022 ; EN 55024

In case of inverter fault, remove and keep any accessory boards installed inside the inverter before shipping it to ABB. Any accessory board will not be reinstalled in case of inverter replacement.

Contact us

www.abb.com/solarinverters

QIG UNO-DM-PLUS Ethernet COM KIT-Quick Installation Guide EN-RevC

EFFECTIVE 15-02-2018

© Copyright 2018 ABB. All Rights Reserved.

Specifications and illustrations are subject to change without notice.

